



BC166AA



Pos.	Signify	Spare parts-Nr.	Quantity	Pos.	Signify	Spare parts-Nr.	Quantity
1	Lever,w/logo-set	B961483AA	1 Set				
2	Indicator cap	B964696NU	1 Pcs.				
3	Rosette	B961484AA	1 Pcs.				
4	Screw M38x1.5	B961474NU	1 Pcs.				
5	Cartridge Ø35mm	B961475NU	1 Pcs.				
6	Ball joint M24x1	A960063AA	1 Pcs.				
7	Perlator M24x1-A	B964943AA	1 Pcs.				
8	Pop-up waste-plastic	B961096NU	1 Pcs.				
9	Connecting set	B960999NU	1 Set				
10	Fl.pexhose G3/8,L445mm	B960535NU	1 Pcs.				
11	Pop up waste-compl.	B964606AA	1 Pcs.				



Pos.	Signify	Spare parts-Nr.	Quantity	Pos.	Signify	Spare parts-Nr.	Quantity
1	Lever,w/logo-set	B961483AA	1 Pcs.	14	Pop up waste shackle		1 Pcs.
2	Screw M5x8		1 Pcs.				
3	Indicator cap	B964696NU	1 Pcs.				
4	Rosette	B961484AA	1 Pcs.				
5	Screw M38x1.5	B961474NU	1 Pcs.				
6	Cartridge $\varnothing 35$ mm	B961475NU	1 Pcs.				
7	Body bidet		1 Pcs.				
8	Ball joint M24x1	A960063AA	1 Pcs.				
9	Perlator M24x1-A	B964943AA	1 Pcs.				
10	Pop-up waste-plastic	B961096NU	1 Pcs.				
11	Connecting set	B960999NU	1 Set				
12	Flex pexhose G3/8 M10x1/L445mm	A963600NU	1 Pcs.				
13	Pop up waste-compl.	B964606AA	1 Pcs.				