



B1394AA

Pos.	Signify	Spare parts-Nr.	Quantity	Pos.	Signify	Spare parts-Nr.	Quantity
1	Handle	B964727NU	1 Set				
2	Valve G1/2 8x20	B961469NU	1 Pcs.				
3	Body-wall basin		1 Pcs.				
4	O-Ring Ø13x2.5	B960137NU	1 Pcs.				
5	Tub.spout S200mm-compl.	B964967AA	1 Set				
6	Perlator M22x1-B	B964945AA	1 Pcs.				
7	S-connection compl.		1 Pcs.				
8	S-connections G1/2xG3/4		2 Pcs.				
9	Metallrosette	A963489AA	1 Pcs.				
10	Fibre washer		2 Pcs.				
11	Nipple M19x1.5 LH		2 Pcs.				
12	O-Ring Ø15.6x1.78		2 Pcs.				
13	Coupling nut		2 Pcs.				